



Yamazing

Quick Start Guide



Get to Know Your Remote



Channel 0 controls all channels from 1 to 15.

Adjusting Your Shades Upper/Lower Limits


Your remote should come pre-paired with your shades with upper and lower limits already preset. Each channel is set up to control one single window treatment.

If the upper or lower limits are not set perfectly, follow the steps below to make adjustments.

Upper/Lower Limit Adjustment


1. Select the correct Channel

Use the +/- buttons to set the remote channel for your roller shade. Avoid channel 0, as it controls all shades.




2. Move Shade to Desired Limit

Press Up for the upper limit or Down for the lower limit. Wait until the shade reaches its destination.




3. Hold both Up and Down for 2s

The motor will jog, and the motor LED will start blinking orange. The motor is now in limit adjustment mode.



4. Adjust with Up/Down

Use the remote to fine-tune the position of the limit. Pressing Up/Down will move the position of the shade incrementally by 1/2 to 1 inch.



5. Press Stop for 2s

The motor will jog, and the motor LED will stop blinking. Your new limit has been saved. Repeat the operation for the other limit if necessary.

